

ELECTRIC SLOW COOKER

Instruction manual



TMJ-6507



TMJ-6511



Dear consumer, Please read these instructions carefully before use in order to avoid damage due to incorrect use and to better understand the functions of this product. Please pay particular attention to the safety guide.

If you pass the device on to a third party, these Operating Instructions must also be handed over.

Please keep them for future references.

IMPORTANT SAFEGUARDS

- Please read these instructions carefully before use.
- Keep present instructions for future references.
- Check that your mains voltage corresponds to that stated on the appliance.
- Only use the appliance for domestic purposes and household or similar applications such as:
 - staff kitchen areas, in shops, offices and other working environments;
 - By clients in hotels, motels and other residential type environments;
 - Environment type like : • Farm Houses • Bed and Breakfast.
- Only use the appliance in the way indicated in these instructions.
- Never use this unit near bathtub, shower, wash-hand basins or other containers with water.
- Never use this apparatus near water projections.
- Never use this apparatus with the wet hands.
- If, unfortunately the apparatus is wet, immediately withdraw the cord of the socket-outlet.
- Inform potential users of these instructions.
- Never leave the appliance unsupervised when in use.
- The appliance must be used only for its intended purpose. No responsibility can be taken for any possible damage caused by incorrect use or improper handling.
- Children and persons with disabilities are not always aware of the danger posed by the use of appliances.
- This device can be used by children aged 8 years and older and adults, with reduced physical, sensory or mental capabilities or lack of experience and knowledge, if they have been given supervision or instruction concerning use of the

appliance in a safe way and understand the hazards involved.

- ❑ This device is not a toy, do not leave children or people with disabilities to play with.
- ❑ Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- ❑ Keep the appliance and its cord out of reach of children aged less than 8 years old.
- ❑ In order to ensure your children's safety, please keep all packaging (plastic bags, boxes, polystyrene etc.) out of their reach.
- ❑ Caution ! Do not allow small children to play with the foil :
THERE IS A DANGER OF SUFFOCATION !
- ❑ From time to time check the cord for damages. Never use the appliance if cord or appliance shows any signs of damage.
- ❑ Never immerse the appliance in water or any other liquid for any reason whatsoever.
- ❑ Never place it into the dishwasher.
- ❑ Never use the appliance near hot surfaces.
- ❑ Do not operate the appliance with a damaged cord or plug, or after the appliance has been damaged in any manner.
- ❑ If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- ❑ Warning: avoid spillage on the connector.
- ❑ Warning: potential injury from misuse
- ❑ The heating element surface is subject to residual heat after use.
- ❑ Disconnect the power source cable before any operation of cleaning of maintenance and accessories assembly.
- ❑ Never use the appliance outside and always place it in a dry environment.

- ❑ Never use accessories, which are not recommended by the producer. They could constitute a danger to the user and risk to damage the appliance.
- ❑ Never use any other connector than the one provided.
- ❑ Never move the appliance by pulling the cord. Make sure the cord cannot get caught in any way.
- ❑ Never wind the cord around the appliance and do not bend it
- ❑ Ensure that the power cord does not come into contact with hot parts of this unit.
- ❑ Make sure the appliance has cooled down before cleaning and storing it.
- ❑ The temperature of accessible surfaces may be very high when the appliance is operating. Never touch these parts, of apparatus, to avoid burning itself.
- ❑ Make sure the appliance never comes into contact with flammable materials, such as curtains, cloth, etc...& the power cord and plug do not come in contact with water.
- ❑ Before cleaning, always unplug the appliance from the power supply and let it cool down.
- ❑ This appliance is not intended to be operated by means of an external timer or separate remote-control system.
- ❑ Always place the unit on a flat surface. Ensure, also, not to cover the device and not to put anything on it.
- ❑ Always remove the plug from the wall socket when the appliance is not in use.
- ❑ When using an extension lead always make sure that the entire cable is unwound from the reel. Use solely CE approved extension leads. Input power must be at least 16A, 250V, 3000W.
- ❑ Incorrect operation and improper use can damage the appliance and cause injury to the user.
- ❑ This device, designed for home use, complies with standards relating to this type of product.

- The appliance must be used and rested on a table or flat & stable surface.
- The item must not be left unattended when it is connected to main supply.
- The item is not to be used, if it has been dropped or if there are visible signs of damage or if it is leaking.
- Regarding the instructions for cleaning, thanks to refer to the below paragraph of the manual.
- This appliance is only intended for household use.

(*) **Competent qualified person** : after sales department of the producer or importer or any person who is qualified, approved and competent to perform this kind of repairs.

GENERAL INFORMATION

The symbol "OPEN BOOK" means a recommendation to read important things contained in the record.



The symbol "BIN" crossed out, abbreviation WEEE (Waste of Electrical and Electronic Equipment) means that at the end of life, it should not be discarded with household waste, but filed to the sorting of the locality. Waste recovery can help preserve our environment.



The symbol "CE" is the guarantee of compliance with harmonized European standards, voluntary, reflecting the essential requirements into technical specifications. These standards are not mandatory but are guarantees of compliance with essential requirements.



The symbol "GLASS / FORK" means that the device is compatible and can come into contact with foodstuffs.

The symbol ROHS (Restriction of use of some Hazardous Substances) on the Environmental Protection, certifies that for each of the five hazardous substances • Lead • Mercury • (hexavalent) chromium • products for protection against flames PBB and PBDE, the peak concentration is equal to or less than 0.1% of the weight of homogeneous material, and 0.01% for the 6th • cadmium.



The symbol "HOT WALL" warns the user that the walls of the unit can become very hot, and to take precautions as required.



The symbol "TRIMAN" indicates that the consumer is invited to dispose the product as part of a separate collection (eg recycling bin, waste, voluntary intake point).



For more information : <http://www.quefairedemesdechets.fr>

WARNING: BURN HAZARD.

- During operation, the temperature of the appliance surface may be hot.
- The heating parts remain hot, long time after stopping the machine.
- The symbol "Hot Surface" warns the user that the apparatus walls may become hot, and to take precautions.



FIRST USE

- Before first use, remove the device and all accessories.
- Clean the apparatus according to the instructions in "Cleaning and Maintenance" paragraph.
- Place the machine on a suitable flat, stable surface.

- Read all instructions in this manual, in accordance with the operating instructions and safety.
- Keep these instructions and advise potential users.

CAUTION :

- ☐ *Never fill with food or water the heating tank cooker.*
- ☐ *Do not use the appliance without the removable container*
- ☐ *Do not use if the ceramic pot is empty.*
- ☐ *The maximum capacity of the removable container is 6.50 L.*
- ☐ *The slow cooker should only be used with removable container provided.*
- ☐ *Do not move the device during operation and after use to avoid burning.*
- ☐ *Always handle the slow cooker, the removable container or lid by the handles.*
- ☐ *Use insulated gloves if necessary.*
- ☐ *Do not use the appliance outdoors.*
- ☐ *Unplug the appliance does not operate normally, whether moving or when servicing.*
- ☐ *The elements of the device are not compatible with conventional oven or microwave.*
- ☐ *This device has been designed for domestic use only.*
- ☐ *Any commercial use, inappropriate use or failure to comply with instructions, not commitment or responsibility or the manufacturer's warranty.*

USE

- Unroll the power cord completely.
- Check that the tension in force in the country where you are, corresponds to that indicated on the apparatus.
- Connect the apparatus in a correct socket-outlet, (and connected to the ground if the unit is Class I), to avoid any danger.
- Disconnect the power source cable before any operation of cleaning of maintenance and accessories assembly.
- Never modify the appliance in anyway.
- Stand the appliance on a table or flat & stable surface.
- The item must not be left unattended when it is connected to main supply.
- The item is not to be used, if it has been dropped or if there are visible signs of damage or if it is leaking.

CAUTION : The ceramic bowl should never be placed on a cooktop or gas.

Cooking

- Check that the selector is turned off. (0)
- Place food : vegetables, meat, etc.. in the removable container.
- Add the desired quantity of water in the removable container.
(0.5 L MINIMUM)
- Place the cover on the removable container.
- Place the removable container, in the slow cooker.
- Verify that the removable container is placed correctly and the side handles are aligned to avoid any accidental leakage of steam.
- Turn the selector to the desired position : **MAXIMUM - SOFT OR KEEP WARM.**
- Do not touch the outer body of the cooker during operation because it gets warm.
- After use, turn the selector to the off position (0), unplug the unit and let it cool.
- Carefully remove the removable container by handling with insulated gloves by the side handles.
- Place the removable container on a stable and heat resistant surface.
- After cooking, add herbs or spices to the food.
- Clean the removable container after each use.

*Notes : Do not exceed the MAXIMUM 6,5L volume to prevent overflow.
It is recommended that not to cut foods directly into the removable container so as not to damage it.*

COOKING TIPS

- As very little quantity of water evaporates during slow cooking, reduce by half the amount of liquid in the original recipe traditional cooking.
- Precook or "launder" strong flavoured vegetables before placing in the slow cooker (spinach, cabbage).
- Reduce the amount of prescribed onions in a recipe, because their flavour increases in this type of cooking.
- Reduce the amount of seasoning in proportion to the reduction of fluid.
Use leaves and herbs seasoning whole spices rather smashed or ground.

Warning : Milk & dairy turn ! replace it by undiluted condensed soups canned or dried milk.

Otherwise, add it just before serving.

The Ceramic Bowl cannot withstand sudden temperature changes, such as immersion into cold water as this can cause the bowl to crack or to break.

Guide to slow cooking

It's a gentle method of cooking retaining both the flavour and the nutrients in food. It allows cheaper cuts of meat to be selected which will become tender and succulent.

More delicate foods such as fish, fruit and vegetables won't break up during cooking.

As the temperature is low, very little sticking occurs and very little stirring is required.

Select the temperature setting that you require :

- **HIGH** : Your Slow Cooker will cook on HIGH until desired temperature is reached and then maintain a constant temperature. A dish will take about 3-4 hours to cook on high position.
- **LOW** : To cook gradually throughout the day or overnight. It will cook in 5-7 hours on LOW position.
- **WARM** : To keep food warm

HIGH-pre-cooking

Pre-browning must always be carried out in a saucepan or frying pan.

Browning meat and vegetables first gives improved results in terms of flavour and appearance, sauces will become thicker.

Cooking time will be shorter than with the no-pre-cooking method.

General guidelines

1. Always ensure that hot (not boiling) liquid is used, never use cold liquid.
2. Always wear oven gloves when handling the slow cooker in use.
3. Dried beans e.g. dried kidney must always be soaked overnight. They should be boiled for 10-15 minutes before placing them into the slow cooker.
4. Add tinned beans 30-45 minutes before the end of the cooking time.
5. Rice, noodles and pasta are not recommended for long cooking time (except pudding rice). Cook them separately and then add during the last 30 minutes.
6. Never place frozen meat or poultry in the slow cooker. It must always be thoroughly defrosted first.
7. When cooking a meat and root vegetable combination always place the root vegetable at the bottom of the bowl as they take longer to cook.
8. Do not fill the cooker to the brim with food.

9. Always cook with the lid on and the ceramic bowl in position.
10. Vegetables such as carrots, potatoes and turnips require longer cooking than many meats. Place them on the bottom of the bowl and cover them with liquid.
11. If adding fresh milk or yoghurt, this should be done during the last 2 hours.
Dried milk may be added at the start of cooking.

NOTES : *Remember that frequent lifting of the lid during cooking will extend cooking time.*

The times stated are only a guide and will depend on a number of factors e.g. quality of ingredients, size of meat and vegetables, quantities, etc.

Slow cooking occurs at a temperature around boiling point. Liquids do not boil quickly at this temperature, there is little steam or evaporation.

Many of your favourite recipes can be adapted to the slow cooker.
Use the following table as a guide.

If Stated recipe time is	Cook on LOW	Cook on HIGH
30 minutes	4 - 6 hours	3 - 4 hours
+/- 60 minutes	6 - 8 hours	5 - 6 hours
1 - 3 hours	8 - 12 hours	7 - 8 hours

Long cooking - Adding water

When you need to add water (or some other ingredient) during long cooking :

- First put the selector in 0 position.
- Take off carefully the lid, and add warm or hot water, in the removable recipient.
- NOTE: Take all necessary precautions to avoid splashing and / or scalding.*
- Replace the cover.
- Set the selector back to the desired position.

At the end of cooking, turn the selector to 0 to turn off the appliance and unplug it.

CLEANING AND MAINTENANCE

Before cleaning, Always : switch off the appliance, disconnect the apparatus and let it cool.

Clean the outside of the apparatus with a sponge or slightly wet linen.

The parts (removable) in contact with food like plate, bowl, forks, Spatula etc. can be washed in hot water with sponge and soft detergent or put in the dishwasher.

Never plunge the apparatus in water or all other liquid !

Do not use abrasive cleaners, gritting, or metal brush or another cutting object.

STORAGE

- Ensure the unit is completely cool and dry.
- Do not wrap the cord around the appliance, as this will cause damage.
- Keep the appliance in a cool, dry place and out of reach from children.

GUARANTEE

Before being delivered, all our products are subjected to a rigorous control. This apparatus is guaranteed 24 months starting from the date of purchase by consumer.

The documents in proof of guarantee are :

- The invoice and
- The filled and stamped warranty plate (located on side or bottom of the gift box). Without these documents in proof, no free replacement, nor no free repair, can be carried out.

During the warranty period, we deal for free, the defects of the apparatus or the accessories, rising from a defect of materials or manufacture by repair or, replacement. The services within the framework of the guarantee do not involve any extension of the warranty period and does not give right to a new guarantee ! In the event of recourse to the guarantee, bring back the complete apparatus to your retailer, in its original packing, accompanied by the proofs of purchase.

The breakage of parts out of glass or plastic is, in all the cases, not warranted. Defects on the accessories or the wearing parts (for example: coals of engines, hooks, drive belts, remote control of replacement, teeth brushes of replacement, webs etc) as well as cleaning, maintenance or it replacement of wearing parts are not guaranteed and are thus to pay !

In the event of foreign intervention, the guarantee becomes null and void.

After flow of the warranty period, repairs can be carried out, against payment, by a specialized trade or a repair service.

SPECIFICATIONS


Power supply	220-240V~ 50-60Hz
Power	320W
Norm	Class I

MADE IN PRC

The characteristics can change without prior notice.

This unit is equipped with an electrical outlet with earth and must be earthed in an according plug.

Note : In the event of question concerning the earth or electric connection, please consult a qualified personnel.



In the event of short-circuit, earthing reduces the risk of electric shock while making possible the current to be evacuated by the wire of ground.

CAUTION: In order to minimize the risks of electric shock, In the event of breakdown, not to open the case but to call upon a qualified technician for repairs.

This device complies with EC directives, it was controlled according to all current European directives, applicable such as: electromagnetic compatibility (EMC) and low voltage (LVD).

This device has been designed and manufactured in compliance with the latest regulations and technical requirements for safety.

**Imported by Sotech International
" LE PERIPOLE " N°A-107
33, Avenue du Marechal de Lattre de Tassigny
94120 Fontenay sous-bois - France**